



Feathers and Wedges

A time tested way to split stone. Available in a variety of sizes.

Miles Supply part #s for feathers & wedges or called shims & wedges. (the "kit" has 2 shims & 1 wedge.)

**denotes [sold directly on milessupply.com](http://milessupply.com)

- AS0011 KIT - 3/4" x 4" SHIMS/WEDGE SET **
- AS0012 KIT - 1/2" x 2 3/4" SHIMS/WEDGE SET **
- AS0013 KIT - 3/8" x 2 1/2" SHIMS/WEDGE SET
- AS0014 KIT - 1 1/4"-1 3/8" x 8" SHIMS/WEDGE SET **
- AS0015 KIT - 1 1/2"-1 3/4" x 18" SHIMS/WEDGE SET
- AS0059 WEDGE 8 1/2 x 2 LIFTING B-0307
- AS000379 SHIMS/WEDGE 5"
- AS000380 SHIMS 1 1/8" x 6 x 14 ROCK BUSTER
- AS000381 SHIMS 1/2" HOLE 2 3/4" DEPTH **
- AS000382 SHIMS 3/4" HOLE 4" DEPTH **
- AS000383 SHIMS 3/8" HOLE 2 1/2" DEPTH
- AS000384 SHIMS 1 1/2"-1 3/4" HOLE 36" DEPTH
- AS000385 SHIMS 5/8" HOLE 3" DEPTH

- AS000387 WEDGE 1 1/2"-1 3/4" HOLE 18" DEPTH
- AS000388 WEDGE 3/4" x 1 1/2" x 8" STEEL 883
- AS000389 WEDGE 1 1/4" HOLE 12" DEPTH
- AS000390 WEDGE 1 1/4"-1 3/8" HOLE 8" DEPTH
- AS000391 WEDGE 1 1/8" x 6 x 14 ROCK BUSTER
- AS000392 WEDGE 1/2" HOLE 2 3/4" DEPTH **
- AS000394 WEDGE 3/4" HOLE 4" DEPTH **
- AS000395 WEDGE 3/8" HOLE 2 1/2" DEPTH
- AS000396 WEDGE 1 1/2"-1 3/4" HOLE 36" DEPTH
- AS000397 WEDGE 5/8" HOLE 3" DEPTH
- AS000398 WEDGE 5/8" x 2" x 6" TSH
- AS000482 SHIMS 1 1/2"-1 3/4" HOLE 18" DEPTH
- AS000483 SHIMS 1 1/4" HOLE 12" DEPTH
- AS000484 SHIMS 1 1/4"-1 3/8" HOLE 8" DEPTH

If you do not see the size you need call us or comment in the [Request for Quote form](#).

800.396.8049 VT 888.283.5863 GA
 800.789.0815 MN 888.278.8383 PA
 844.883.4108 TX 815.847.0080 IL

How to Use:

1. Drill holes along your split line at least as deep as your wedges are long and about 6" apart.
2. The feathers and wedges should fit snugly into the hole.
3. The split line may be straight or curved.
4. For more difficult splits, be sure to drill the holes deeper and closer together.
5. Insert feathers and wedges into the holes.
6. Be sure the wings face the direction you want the stone to split.
7. Strike the wedges in sequence, firmly, but not forcing. Wait a few minutes, then repeat until stone is split.



Popular sizes sold directly from our website:

- AS0011 KIT - 3/4" x 4" SHIM/WEDGE SET**
- AS0012 KIT - 1/2" x 2-3/4" SHIM/WEDGE SET**
- AS0014 KIT - 1-1/4"-1-3/8" X 8" SHIM/WEDGE SET**
- AS000381 SHIM 1/2" HOLE 2-3/4" DEPTH**
- AS000382 SHIM 3/4" HOLE 4" DEPTH**
- AS000392 WEDGE 1/2" HOLE 2-3/4" DEPTH **
- AS000394 WEDGE 3/4" HOLE 4" DEPTH **